



MASTECH

V-STROM 650/1000 AT/XT 17-UP

Montaje soporte maleta superior



Nota:

No apriete todos los tornillos hasta que no estén completamente alineadas todas las perforaciones con respecto a los puntos de sujeción.

Antes de realizar la instalación, verifique todo el manual e identifique que las partes y las piezas estén completas.


Herramientas:

Kit llaves hexágonas

Kit llaves Boca Fija



Kit Instalado




Instalación

esquema 1



PUNTOS DE SUJECIÓN EN
LOS LATERALES DE LA MOTO

esquema 2



PUNTOS DE SUJECIÓN EN
LA BASE ORIGINAL

- 1- Desinstale los tornillos originales de la moto mostrados en el ESQUEMA 1
- 2- Instale los soportes laterales utilizando la tornillería mostrada en el DIAGRAMA.
- 3- Instale la platina superior e inferior utilizando la tornillería y los puntos de sujeción como lo indica el ESQUEMA 2

El Kit Contiene

Platina Aluminio base top case PLA1 Cantidad: 1	Platina enganche trasero inox PLA2 Cantidad: 1	Platina Acero Lateral PLA3 Cantidad: 2	Tornillo Avellanado M8 X 60 T1 Cantidad: 2	Tornillo bristol M6 x 50 T2 Cantidad: 4	Moneda avellanada anclaje inox BUJ1 Cantidad: 2
Wasa M6 TC1 Cantidad: 4	Tuerca seguridad M6 TC2 Cantidad: 2	Buje aluminio ALT 23 mm BUJ2 Cantidad: 2	Buje aluminio ALT 24.5 mm BUJ3 Cantidad: 4	Arandela M6 ARA1 Cantidad: 2	Tornillo avellanado M6 x 30 inox T3 Cantidad: 2

Al terminar la instalación de las partes, verifique que estén alineadas y que toda la tornillería esté debidamente apretada; reajuste todos los tornillos.




MASTECH

V-STROM 650/1000 AT/XT 17-UP

Montaje soporte maleta superior

 Esp/Spa  Ing/Eng

Diagrama



Al terminar la instalación de las partes, verifique que estén alineadas y que toda la tornillería esté debidamente apretada; reajuste todos los tornillos.

Calle 76 # 52D - 74 / Telefax: (57+4) 448 8428 / Medellín - Colombia
www.mastechno.com

Assembly Instructions top case rack for mastech pannier

Note :


Do not tighten the screws until they are completely aligned with the holes.
Before the installation, please verify through the manual that all pieces and parts are complete.

Tools Required:

Hex Allen Wrench Set
Combination Wrench Set



Assembled Kit



Installation





ATTACHMENT POINTS ON
THE SIDES OF THE MOTORCYCLE




ATTACHMENT POINTS ON
THE ORIGINAL BASE

- 1- Uninstall the original motorcycle screws shown in SCHEME 1
- 2- Install the side supports using the hardware shown in the DIAGRAM
- 3- Install the upper and lower plates using the hardware and fastening points as indicated in SCHEME 2

installation Kit

Platina Aluminio base top case  PLA1 Cantidad: 1	Platin hitch stainless butt  PLA2 Cantidad: 1	Steel plate Side  PLA3 Cantidad: 2	Countersunk screw M8 X 60  T1 Cantidad: 2	Tornillo bristol M6 x 50  T2 Cantidad: 4	Countersunk coin stainless anchor  BUJ1 Cantidad: 2
Wasa M6  TC1 Cantidad: 4	Safety nut M6  TC2 Cantidad: 2	Aluminum bushing height 23 mm  BUJ2 Cantidad: 2	Aluminum bushing height 24.5 mm  BUJ3 Cantidad: 4	Washer M6  ARA1 Cantidad: 2	Countersunk screw M6 x 30 stainless  T3 Cantidad: 2

Diagram



After the installation of the parts, please check that they are aligned and that all the hardware is properly tightened